

# **MPAD-C 12-24V**

# Ceiling microwave presence/absence detector 12-24V AC/DC

### Overview




The MPAD-C 12-24V Microwave presence detector provides automatic control of low voltage loads including lighting and BMS systems with optional manual control. The MWS6-PRM detects movement using a highly sensitive microwave detector. This works by emitting low power microwave signals and measuring the reflections as the signals bounce off moving objects.


Functioning as a presence detector, the unit can turn lights on when a room is occupied and off when the room is empty. Optional settings allow lights to be turned off in response to ambient daylight.

All functionality is fully programmable using an IR handset.

### **Features**

### Front features





### **Microwave Sensor**

Detects movement within the unit's detection range, allowing load control in response to changes in occupancy.

#### IR Receiver

Receives control and programming commands from an IR (infrared) handset.

### **Light Level Sensor**

Measures the overall light level in the detection area

#### **Status LEDs**

The LED flashes Red to indicate the following:


| Walk Test LED active   | - when movement is detected |
|------------------------|-----------------------------|
| Valid setting received | <u>₩</u>                    |

### **Power Input & Output Connector**

Used to connect power to the unit and to connect a switched load.

### **Switch Input Connector**

Two input terminals can be used to manually override the lights on or off.



Area of high sensitivity Area of lower sensitivity

Note. If the range is compromised by the ceiling construction / material. Add the supplied 20mm spacer ring. See page 4 for fitting details.

# **Sensor functionality**

### **Detection Mode**


The Detection Mode can be set to behave in Presence or Absence mode:

- **Presence** When movement is detected the load will automatically turn on. When the area is no longer occupied the load will automatically switch off after an adjustable time period.
- **Absence** The load is manually switched on. When the area is no longer occupied the load will automatically switch off after the adjustable time period has elapsed.

In either case, sensitivity to movement of the Microwave sensor can be adjusted using the Sensitivity parameter. HINT: To assist in setting the Sensitivity, turn on the Walk Test LED which will flash red when movement is detected.

### Switch Level On/Off

Occupancy detection can be made dependant on the ambient light level using the Lux On Level and Lux Off Level parameters.




### **Choosing a Suitable Location**


The detector should be sited so that the occupants of the room fall inside the detection pattern shown opposite).

- Avoid positioning the unit where direct sunlight may enter the sensor element.
- Do not site the sensor within 1m of any lighting, forced air heating or ventilation.
- Do not fix the sensor to an unstable or vibrating surface.
- Avoid metallic objects directly in front of the sensor head.

### Input and switch connections



### Load connections



### Absence detection

- To use absence detection a retractive (momentary) switch must be connected between the 2 terminals on the diagram.
- The unit ships with presence detection as default. To change to absence detection, press and release the external switch 5 times within the first minute of power up. The LED will turn on solid for 30 seconds to indicate absence mode has been selected.
- To change back to presence detection, repeat the above procedure—the LED will flash for 30 seconds to indicate presence mode has been selected.

**Note:** the above adjustments can also be made using the HHIR-PROG or HHIR-LCD-PROG handsets. See Programming sections.

## Power-up test procedure

When power is applied to the unit, the load will turn on immediately.

Set the timeout to 10 seconds, vacate the room or remain very still and wait for the load to switch off .

Check that the load switches on when movement is detected.


The unit is now ready for programming.

### Installation


The MPAD-C 12-24V is designed to be mounted using either:


- Flush fixing, or
- Surface fixing, using the optional Surface Mounting Box (part no. SB-C).

Both methods are illustrated below.



### Wire stripping details





### Important

Ensure that the cables are formed as shown before affixing the cable clamp. The clamp MUST clamp the outer sheath(s) only.

Bend cores as shown.

# Readback function (HHIR-LCD-PROG handset only)

The HHIR-LCD-PROG has the ability to read back the settings stored in a device.

### To read back individual parameters

Navigate to the parameter and press the 'R' (Read) button whilst pointing at the device. The handset will click
when the parameter has been read back, the device will flash its LED, and the value will be shown against the
parameter in the menu.

### To read back all of the parameters in a menu

- Press and hold the 'R' (Read) button for more than 1 second.
- The handset will click every time a parameter is received
- The device will show multiple flashes of its LED
- All of the values will be shown against the parameters in the menu.
- The individual parameters may be edited and then saved as a 'Macro'.

### Notes

- If a parameter(s) has been missed because of a communication error, the missing value(s) is replaced by dashes.
- When reading back, the Channel 1 relay (where fitted) will temporarily be switched off, and will return to it's normal state 2 seconds after the read back has been completed.

## **Basic programming**



The functionality of the MPAD-C 12-24V is controlled by a number of parameters which can be changed or programmed by any of the following devices:

- HHIR-PROG Infrared Handset. See below for programmable functions.
- HHIR-LCD-PROG Infrared Handset (with LCD). See user guide for full programming details.

For most basic programming operations the HHIR-PROG handset can be used and the following procedures are based on using this device.

Point the handset at the Sensor and send the required programming commands to the unit as shown below.

Valid commands will be indicated by a red LED flash. See page 1 for details of other LED responses.

|   |                  | Nun Nun                  | nber of Shi              | ft key pres          | ses             |                                 |   |
|---|------------------|--------------------------|--------------------------|----------------------|-----------------|---------------------------------|---|
| Parameter<br>Name                         | Default<br>Value | O O O SHIFT 1 SHIFT 2    | 1<br>SHIFT 1 SHIFT 2     | 2<br>SHIFT 1 SHIFT 2 | SHIFT 1 SHIFT 2 | HHIR-PROG Handset<br>Graphics   | Description   |
|   |                  |                          | Button A                 | ctivation            |                 |                                 |   |
| On  |                  | On                       |                          |                      |                 | ON/RAISE                        | Turn lights on.   |
| Off                                       |                  | Off                      |                          |                      |                 | OFF/LOWER.                      | Turn lights off.  |
| Walk test                                 | Off              | On                       | Off                      |                      |                 | OFF ON WALKTEST                 | When set to On this causes a red LED to flash on the sensor when it detects movement. Use this feature to check for adequate sensitivity levels.  |
| Time Out<br>(Time<br>adjustment)          | 20 mins          | 1, 10 &<br>20<br>minutes | 5, 15 &<br>30<br>minutes | 10<br>seconds        |                 | 5/1 15/10 30/20 IIMEOUT MINUTES | Once the detector is turned on, this value sets how long the lights will stay on once movement has ceased.  |
| Lux on<br>level<br>(Switch<br>level on)   | 9                | 2, 5 & 7                 | 4, 6 & 9                 |                      |                 | LUX ON LEVEL / LIGHT LEVEL      | Lux level setting to prevent the luminaires being switched on if the ambient light level is sufficient (adjustable between 1 and 9). The luminaires will always be switched on at level 9.  |
| Lux off<br>level<br>(Switch<br>level off) | 9                | 2, 5 & 7                 | 4,6 & 9                  |                      |                 | DALI LUX OFF LEVEL DS I         | Lux level setting to switch the luminaires off during occupancy if the ambient light level goes above the setting (adjustable between 1 and 9). Level 9 will always keep the lights on. This setting can be used for "window row switching".  Note: the Lux Off Level value must always be greater than the Lux On Level value. |
| Sensitivity                               | 9                | 1, 5 & 9                 | 3, 6 & 8                 |                      |                 | % % %9                          | Sensitivity level for detecting movement.  1 = low sensitivity  9 = high sensitivity  |
| Defaults                                  |                  |                          |                          | D                    |                 | December                        | Returns the unit to the default settings.   |
| Presence /<br>Absence                     | Presence         | Presence                 | Absence                  |                      |                 | A P<br>PRS / ABS                | Presence mode allows the output to turn on when movement is detected and off when movement ceases. Absence mode allows the output to turn off when movement ceases, but must be manually turned on first.   |
| Shift                                     |                  |                          |                          |                      |                 | SHIFT                           | Use this button to select the settings in red and blue signified by the 'Shift 1' and 'Shift 2' LEDs  |

# **Fault finding**

#### What if the load does not turn ON?

- Check that the supply to the circuit is good.
- If the detection range is smaller than expected, check the diagram on page 2. Rotating the sensor slightly may improve the detection range. If still reduced it may be compromised by the ceiling construction / material. Add the supplied 20mm spacer ring. See page 4 for fitting details.

HINT: The Walk Test LED function can be used to check that the unit is detecting movement in the required area. What if the load does not turn OFF?

- Ensure that the area is left unoccupied for longer than the Time Out Period.
- Ensure that the sensor is not adjacent to circulating air, heaters or lamps.
- The unit may pick up movement through glass, thin partitions or walls. Reduce the sensitivity.


# Advanced programming

| Parameter Name             | Default Value | Range / Options              | Description  | HHIR-<br>PROG | HHIR-LCD<br>-PROG |
|----------------------------|---------------|------------------------------|--|---------------|-------------------|
| Detector Paramete          | ers           |                              |  |               |                   |
| Walk Test LED              | Off           | On or Off                    | When set to On this causes a red LED to flash on the sensor when it detects movement. Use this feature to check for adequate sensitivity levels.   | ✓             | ✓                 |
| Time Out (Time adjustment) | 20 minutes    | 0-99 minutes                 | Once the detector is turned on, this value sets how long the lights will stay on once movement has ceased. Select 0 for 10 second delay – use for commissioning only.  | <b>√</b>      | <b>√</b>          |
| Manual Time Out            | 10 minutes    | 0-99 minutes                 | When a manual operation occurs, either via the switch input or the infrared, it invokes the timeout period.  Example 1: a detector in presence mode has a detector timeout of 15 minutes and a manual timeout of 3 minutes. When the user leaves the room they press the off button. The sensor will revert to automatic after 3 minutes, and then walking back in the room will turn the lights on.  Example 2: using the settings above, the user turns the lights off (say for a presentation) but stays in the room. Every time a movement is detected, the manual timeout period is re-triggered, but when it doesn't pick up for the short timeout period, the sensor will timeout and revert to automatic. This means the lights may turn on inadvertently during the presentation, if the occupants are still for the manual timeout period, so adjust the timing carefully. | *             | <b>√</b>          |
| Sensitivity On             | 9             | 1 (min) to 9 (max)           | Sensitivity level for detecting movement when the detector is already on. *HHIR-PROG sets Sensitivity On and Off to the same value.  | <b>√</b> *    | ✓                 |
| Sensitivity Off            | 9             | 1 (min) to 9 (max)           | Sensitivity level for detecting movement when the detector is off. *HHIR-PROG sets Sensitivity On and Off to the same value.   | √*            | ✓                 |
| Lux time                   | 0             | 0 (disabled)<br>1-99 minutes | If the detector measures the lux level and decides that the output needs switching on or off as a consequence, the lux time must elapse first. If at any time during the timed delay the lux change reverses then the process is cancelled. Lux Time enables absence detection to be implemented with a lux off level set. When the button is pressed, the lights will go on, regardless of ambient light level. However, if there is sufficient ambient light, they will turn off again after the Lux Time. Note that whenever the an external switch is pressed, whether in absence or presence mode, if the lights were out because of the lux level, they will be immediately turned on again for at least the Lux Time.   | *             | <b>√</b>          |
| Power Up State             | On            | On or Off                    | Select No for a 30 second delay on start up. If Yes is selected, there will be no delay on start up and the detector will always power up detecting.   | ×             | ✓                 |
| Inhibit                    | 4 seconds     | 1 to 999 seconds             | When the detector turns off, a delay is instigated to prevent retriggering. In certain circumstances this delay may not be enough. This parameter allows the delay to be changed.  | ×             | ✓                 |
| Factory default            | -             | -                            | Restores factory default settings  | ✓             | ✓                 |

| Switching functions                 |          |  |   |   |   |  |
|-------------------------------------|----------|--|---|---|---|--|
| Detection Mode                      | Presence | Presence or<br>Absence   | Presence mode allows the output to turn on when movement is detected and off when movement ceases. Absence mode allows the output to turn off when movement ceases, but must be manually turned on first. | ✓ | ✓ |  |
| Lux on level<br>(Switch level on)   | 9        | 1 to 9 For a higher resolution a scale of 101-199 is available             | Sets a minimum light level below which the Microwave sensor is enabled, allowing lights to be turned on by movement.  Note: the Lux Level Off value must always be greater than the Lux Level On value.   | ✓ | ✓ |  |
| Lux off level<br>(Switch level off) | 9        | 1 to 9<br>For a higher<br>resolution a scale<br>of 101-199 is<br>available | Sets a maximum light level above which the Microwave sensor is disabled, preventing lights from being turned on by movement.  | ✓ | ✓ |  |

| User Modes   |   |   |  |   |   |
|--------------|---|---|--|---|---|
| Override On  | - | - | If the lights are off, sending the IR command will turn them on immediately and revert to automatic operation using the manual timeout period .                      | ✓ | ✓ |
| Override Off | - | - | If the lights are on, sending the IR command will turn them off immediately. After the manual timeout period (described above), the sensor will revert to automatic. | ✓ | ✓ |
| Cancel       | - | - | Cancels the on or off override, returning the detector to normal operation.  | × | ✓ |

| Switch Input Modes         |         |   |                                  |   |   |
|----------------------------|---------|---|----------------------------------|---|---|
| 1 position switch together | Default | - | Short press on, long press off.  | × | ✓ |
| 2 position switch together | -       | - | Short press on, short press off. | × | ✓ |



# **Technical data**

Dimensions See diagrams opposite

Weight 0.15kg

Supply Voltage Min 11.5VDC max 36VDC, min

10VAC max 26.5VAC

Load Low voltage supply with open

collector output, rating 50mA,

30VDC max

Power consumption On 927mW, Off 576mW

Terminal Capacity 2.5mm<sup>2</sup>
Temperature -10°C to 50°C

Humidity 5 to 95% non-condensing

Material (casing) Flame retardant ABS and PC/ABS

Type Class 2

Microwave frequency 5.8 GHz

Safety The microwave radiation emitted

by these units is extremely low power and complies with ANSI standard "IEEEC95.1-1999 Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic

Fields 3kHz 300GHz."


IP rating IP40

Compliance RED-2014/53/EU


LVD-2014/35/EU



### MPAD-C 12-24V



### SB-C



# Part numbers

Part number Description

Detector MPAD-C 12-24V Ceiling Micro

Accessories SB-C

IPAD-C 12-24V Ceiling Microwave presence/absence detector 12-24V AC/DC Surface mounting box

HHIR-PROG Programming IR handset
HHIR-LCD-PROG Universal LCD IR handset

### **IMPORTANT NOTICE!**

This device should be installed by a qualified electrician in accordance with the latest edition of the IEE Wiring Regulations and any applicable Building Regulations.



Cooper Lighting Solutions Usk House, Lakeside

Llantarnam Park, Cwmbran, NP44 3HD, UK Tel: +44 (0)1633 838088

Fax: +44 (0)1633 867880 info@cooperlighting.co.uk www.cooperlighting.co.uk